

er. Select D drive.




ownload, save, browse,



the menu item of "Uninstall", or
"Remove Programs" applet of

4.4 Main Explanation of the Software Menu



4.5 Video Parameter setting (not applicable on Windows Vista)

This function allows you to choose video color space and video size.



- De-flicker: Set AC frequency of fluorescent light
- AE Speed: Set the frame rate to capture video
- Light Source: Select brightness environment
- Exposure: Set video exposure
- Capture Source: Select capture device
- Device Setting: Adjust various video settings, such as white balance, etc.
- Video format

4.6 Operating Video Mode


1. To operate the camera setting, press the car icon (#1) to enter into the video mode. In the video mode you can take photos of yourself, or use the camera as a web cam.
2. Click icon #2 to snap the photo. After the photo is taken it will be put on the right side of the software screen. You can take as many photos as your hard disk allows.
3. Press icon #3 to go to the photo view mode. In the photo view mode you can view photos taken and stored in the camera.



The following screen will allow you to choose video resolution and picture clarity.



4.7 Download File

Connect the mini digital camera to your computer via USB cable, then double click shortcut  on the computer desktop. the following figures will pop up:





Click "YES", all photos will be transferred to your PC.

4.8 Browse File

Select the photo in application window on the right side. The photo will be shown in the application window on the left side as actual size.

4.9 Save File

- Press button  to save one file which you have selected
- Press button  to save all files

4.10 Play AVI File

After downloading video, the images will show in the screen below. (Download method is the same as that of photos.)







Click AVI play button to start (Note: You must have or install a Windows Media Player or Real Player.)

4.11 PC-CAMERA

Connect the mini digital camera with your computer via USB cable, then double click the shortcut  on your computer desk. The following interface will appear:



- Press button  to work as PC-Camera
- Press button  to stop PC camera
- Press button  to start preview video image
- Press button  to capture the current frame